


# Application Diagram

Synchronization and load sharing with automatic load depending start and stop of four diesel generators



Main office:  
 Betonvej 10, DK-4000 Roskilde, Denmark  
 Phone: + 45 7026 1122, Fax: + 45 7026 2522  
 e-mail: selco.dk@selco.com, Internet: www.selco.com

Subsidiary:  
 3 Blackhorse Lane, Ipswich IP1 2EF, United Kingdom  
 Phone: +44 (0) 1473 210544, Fax: +44 (0) 1473 230439  
 e-mail: selco.uk@selco.com, Internet: www.selco.com